

# prompt<sup>®</sup>


The pursuit of purity


Our ideas and innovations are a part of the pursuit of maintaining the sanctity of milk so that the world's most ancient health drink can be appreciated as it truly is - untouched and unadulterated.

 Presence across 28 states


 Presence across 350+ districts


 Presence across 68,000+ villages

 900+ team members

 Legacy of more than 3 decades

 8 patented products

 220+ serviceable locations

 24x7 support via mobile app

## Optimise your farm with related products

### MilkEasy Milking Machine

MilkEasy Milking Machine is designed to milk cattle quickly, efficiently, hygienically, and ensuring maximum comfort to the animal.



### Farm 365 Animal Husbandry App

This technologically advanced app is a complete solution to your cattle management needs, which helps improve cattle breeding and feeding, resulting in increased milk yield and profitability.



Prompt Equipments Pvt. Ltd.

7th Floor, Shaligram Corporates, C. J. Road, Iskon - Ambli Road, Ahmedabad Gujarat - 380058 (India)

Ph: 02717 45 1111/6111 | info@promptdairytech.com | www.promptdairytech.com

Follow us on 

**milko  
chill**<sup>™</sup>  
Instant Milk Chiller



**prompt<sup>®</sup>**  
The pursuit of purity

**MILKCHILL  
INSTANT MILK CHILLER**

## How do we keep it pure?

Prompt provides innovative solutions for an efficient dairy supply chain. From farm management and milk collection to quality analysis and preservation, we have different software and equipment to ensure that the purity of milk is maintained at every step. Our unique offering, the MilkoChill is a patented technology that brings the benefits of instant milk

chilling right at the doorsteps of a farmer. The system provides for instant chilling of milk even in the absence of electricity to ensure that the quality of milk is retained and bacterial growth is arrested at the source. MilkoChill ensures the purity of the milk is preserved at the farmer's doorstep to provide a better return to them.

## Our product in this pursuit – Prompt's MilkoChill, A Revolutionary Instant Milk Chiller


### AN INNOVATIVE AND AFFORDABLE INSTANT MILK CHILLER THAT CHILLS MILK AT SOURCE

India is world's largest producer of milk and most of the milk is produced by small holder dairy farmers. However, quality needs to be improved. One key factor affecting quality is the time lag between milking and the first chilling. Milk being a highly perishable product needs to be chilled at the earliest to arrest bacterial growth and retain its quality. Our innovative and affordable instant milk chiller makes it possible to chill milk at source - thereby reducing spoilage, retaining quality, increasing shelf life and hence increasing farmers' income. MilkoChill can chill 250 litres of milk instantly in one hour. Our solution is based on a unique thermodynamic design, using key patents in the field of heat transfer, that results in maximum heat transfer with lowest energy consumption. Keeping in mind the non-reliable electrical grid supply in remote villages, our system is designed with a thermal storage mechanism which stores energy whenever electricity is available. This thermal battery reduces the farmer's dependence on electricity at the time of chilling. Our system also offers the flexibility to connect with alternative renewable energy source like solar power (free sustainable energy). This eliminates the need for diesel generator, thus reducing operating costs.



160 Ltr. (80 Ltr. Per Session)

 Instantly chills 250 litres in 1 hour

 Generates 100 litres of hot water (upto 60°C)

 Low power consumption (~1 kW)

## TECHNICAL SPECIFICATIONS

Model Number	MC500V1A	MC160V1A
Input supply	220V (± 5%), 50Hz, Single Phase	220V (± 5%), 50Hz, Single Phase
Total milk cooling capacity per day	500 Ltr. (250 Ltr. Per Session)	160 Ltr. (80 Ltr. Per Session)
Chilling time	1 hour	1 hour
Rated inlet milk temperature	35°C	35°C
Average milk outlet temperature	7°C	7°C
Quantity of hot water generation per day	100 Ltr. (50 Ltr. Per Session)	NA
Average Outlet temperature of hot water	55°C	NA
Rated thermal bank charging hours per session	5 - 6 hours	5 - 6 hours
Rated compressor power consumption	~1 kW	~0.42kW
Rated total energy consumption per session	6 kWh	2.5 kWh
Net energy recovered in HRU per session	1.5 kWh	-
Net energy consumption per session	4.5 kWh	2.5 kWh
Condenser type	Air Cooled	Air Cooled
Unit dimensions (LxWxH)	1470mm x 822mm x 1825mm	860mm x 760mm x 1340mm
Standing platform dimensions (LxWxH)	1170mm x 660mm x 260mm	NA
CIP module dimensions (LxWxH)	955mm x 400mm x 755mm	540mm x 410mm x 720mm
Main unit weight	Approx. 300 kgs	Approx. 120 kgs
Total weight	Approx. 350 kgs	Approx. 120 kgs
Total weight with water inside	Approx. 650 kgs	Approx. 190 kgs
CIP Module	Semi-Automatic	Semi-Automatic

Note: Performance data is as per lab testing under standard conditions. It is subject to change without notice due to continuous product improvements.

### FEATURES:

- Economical with a good ROI
- Easy to operate and low maintenance cost
- Scalable and compact
- Reduces spoilage and improves shelf life
- Facilitates milk quality management and increases farmer income
- Generates hot water as a bonus from heat recovery
- Can be connected with grid power or solar power

### WHAT ARE ITS BENEFITS?

#### Instant Chilling based on Unique Thermodynamic design

Application of patented evaporator and multi-utility heat pump licensed from IIT, Bombay.

#### Hot water generation

Additionally, up to 100 LPD of hot water, at 55°C, is produced as a by-product from heat recovery which can be used for equipment cleaning-in-place (CIP) and cattle sanitation.