


**prompt**<sup>®</sup>  
The pursuit of purity

# An AI powered digital leap in **complete tracking and monitoring of carton box movement**



INTRODUCING

**prompt**<sup>®</sup>  
**TRACKSURE**

end-to-end carton box management solution

# Leveraging revolutionary Computer Vision Technology to enable real-time tracing of carton boxes

INTRODUCING  
**prompt**<sup>®</sup>



**TRACKSURE**

end-to-end **carton box** management solution

**Meet these  
challenges  
in carton  
box  
traceability  
easily**

Getting accurate traceability data in industries  
with high production speeds

Integrating traceability system with existing production systems

Apprehensions about barcode or RFID readability

Losses from theft, pilferage or improper packing

## Why Prompt TrackSure is a Pro in improving supply chain efficiencies?



Improved accuracy



Reduced labour costs



Increased efficiency



Better management




Enhanced traceability



Easy integration with existing CRM / IT systems



Useful data insights for better decision making



# Prompt TrackSure, at a glance

Tracking flow of packed products in CFC boxes, from manufacturing plant to distribution centers

## ACCURATE & INTELLIGENT: A Real-time Track & Trace System Powered by AI technology


- › Automates the entire process of reading product information and generating and printing QR code
- › Reduces overheads significantly
- › Avoids pilferage and other losses



## PACKAGING SECTION

Providing real-time update of stock transferred

- › Extracting the following information using Industrial cameras that are fixed on packing conveyor for capturing the images of each box having primary packs.
- › SKU-wise count for the box
- › SKU-wise weighing records and rejecting with alarms if needed
- › Timestamp
- › Reading the product information printed on boxes for variant name, SKU details, SAP Code etc.
- › Mapping the product along with weight data and giving input to online QR printer for printing along with pre-filled information such as manufacturing date, expiry date and batch no.



## QR CODE



Unique 8-digit alphanumeric no. with 1 digit fixed  
QR code would contain:

- › Unique ID
- › Batch no
- › Date of manufacturing
- › Date of expiry
- › SKU Name
- › Weight information



- › Printing QR on CFC boxes
- › Reading the QR before entering into warehouse
- › Alert will be generated for any deviation in count between production and warehouse scanning

## STORAGE SECTION

Getting real-time update of stock count and carton transfer details

- › Initiating session from desktop application
- › Capturing QR for each carton on conveyor, at the entrance of storage
- › Difference in count, if any will be notified through alert mechanism
- › Checking result on Web Portal and Mobile app using credentials




## DISPATCH SECTION

Giving real-time updates of stock count and carton uploading details

- › Initiating process with TrackSure app
- › Authenticating driver's detail, using OTP
- › Scanning of QR code using industrial camera or QR reader while loading the vehicle
- › Mapping delivery challan- SKU wise
- › Generating verification report- SKU wise
- › Stop capturing of data and submitting information to server
- › Check results on Web Portal and Mobile app or in scan history



# A quick glance at the carton box movement with **Prompt TRACKSURE**




## Components of TrackSure, a completely digital system



Hardware:  
Industrial camera,  
lights, sensor



QR Printer



Online  
checkweigher  
with rejector



Web portal and  
Mobile app

Scan this QR code  
to know more:



**prompt**<sup>®</sup>  
The pursuit of purity

**Prompt Equipments Pvt. Ltd.**

7<sup>th</sup> Floor, Shaligram Corporates, C. J. Road, Iskcon - Ambli Road,  
Ahmedabad, Gujarat - 380 058 (India)

info@promptdairytech.com | www.promptdairytech.com

Ph: 02717 451111 / 6111 | Follow us on    